

Errata to
Advanced Energy Design Guide for Highway Lodging
January 4, 2010

- Page 73:** Section EL10 refers readers to EL19 for more information on vacancy sensors; it should actually refer readers to **EL9**.
- Page 39:** In the “Roof” row under the column heading “Component,” “Metal building” should read “**Attic and other.**”